



Replaces: 2013-09-06

Date: 2014-10-08

# Tapetklister Special

Tapetklister for application with a wallpapering machine. Suitable for all types of paper wall coverings in dry rooms. Can be used on surfaces such as plasterboard, fibreboard and other wall panel material, as well as on old wallpaper and painted surfaces.

- **Developed for wallpapering machines**
- **Easy to mix, lump-free**
- **Long open time**

## TECHNICAL DATA

**Type:** Carboxymethyl starch mixture  
**Colour:** Dirty white flakes; after mixing, semi-transparent paste  
**Consistency:** Thixotropic (mixed with water)  
**Density:** Approx. 410 kg/m<sup>3</sup>  
**pH:** >9  
**Fire hazard:** No

## APPLICATION DATA

**Work temperature:** Not below +18°C – both surface and material

**Mixing:** – For machines: 1:30 for machine application, or ¾ scoop (6 dl = 0.26 kg powder) to 8 litres of room-temperature water.

– For rollers: 1:25 for manual application or 1 full scoop (7 dl = 0.34 kg powder) to 8 litres of room-temperature water.

Pour the powder in slowly while stirring strongly. Leave to draw for 10–15 minutes, then stir again.

**Material consumption:** 5–6 m<sup>2</sup>/litre

**Application time:** 0–30 minutes. The application time is highly dependent on the amount of adhesive applied, the absorbency of the underlying surface, the temperature and the air humidity.

**Tools:** Roller, paintbrush or wallpapering machine

**Storage time:** 12 months (in unopened packaging). Store in a cool, frost-free place.

## HEALTH AND THE ENVIRONMENT

### Handling and cleaning instructions

Observe good work hygiene. On contact with the skin, wash the adhesive off with soap and water. Clean tools with water before the adhesive dries. Use methylated spirits to dissolve dry adhesive.

For additional information, see the Safety Data Sheet.

## INSTRUCTIONS FOR USE

### Prepare the wall depending on the surface.

- Old wallpaper – remove loose paper wallpaper or the vinyl surface on old vinyl wall coverings.
- Painted surface – wash with 5% ammonia solution/universal cleaner and then rinse with water.
- Filled surface – no preparation.
- Mesh – fill or remove the old mesh.
- Alternatively, apply renovation fabric directly to the old wallpaper/mesh using Casco Premium or Aqua.

Tape over joins and fill any irregularities. Pre-treat weak surfaces or strongly absorbent underlay with a mixture of 1 part powder to 4 parts water. Tapetklister Special can be applied directly to wallpaper or the wall surface. Follow the instructions from the wallpaper producer.

## MIXING

### For machines:

Mix ¾ of a scoop (6 dl = 0.26 kg powder) with 8 litres of room-temperature water.

### For rollers:

Mix 1 full scoop (7dl = 0.34 kg powder) with 8 litres of room-temperature water. Pour the powder in slowly while stirring strongly. Leave to draw for 10–15 minutes, then stir again.

### Pasting and hanging

The paste is specially suitable for wallpapering machines, but can also be applied using a paintbrush



or roller. Fold the lengths of wallpaper. Leave for 5–30 minutes. Hang the lengths of wallpaper and use a wallpaper brush to squeeze out all the air. Wash off any surplus adhesive with a damp sponge. Follow the instructions from the wallpaper producer.

#### PACKAGING

5 kg

---

This information is based on laboratory reports and extensive practical experience. The information is intended for users and designed to help them identify the most appropriate work method. As the production conditions of the individual user is beyond our control, we accept no liability for the actual result of the work, affected by local circumstances. In every case, we recommend testing and ongoing checks

---

Certified according to:



**Sika Sverige AB**  
163 08 Spånga, Sweden  
Tel. +46 8 621 79 00  
Web: [www.casco.com](http://www.casco.com)